

Applying the Ecto-1 Logo Decals

- 1 -

Cut out one of the Ghostbusters logo's and trim very neatly around the edge. Be sure to leave 1 to 2 mm border, as cutting into the coloured areas could result in bleeding of the ink.



- 2 -

Clean the area where the decal is to be placed

- 3 -

Place the decal into water, ensuring it's completely covered by water.



- 4 -

Place the decal onto the panel facing upwards. Now with a little pressure, slide the decal to the side, it should start to separate from the backing. If this does not happen, drop it back into water and wait another 10-20 seconds and try again.

- 5 -

Carefully move the decal into the desired position. Using absorbent cloth, dab and wipe the decal, removing air bubbles and ensuring applied.



Once done, allow to dry and lacquer.

Remember, preparation is key to great results!!